

# Rise by Sawtooth Student Drum Set (ST-RISE-DS)

## Assembly Instructions



Pieces needed for assembly:



Bass Drum 1x



Floor Tom Drum 1x



Tom Drums 2x



Snare Drum 1x




Bass Drum Pedal 1x



Bass Drum Beater 1x



Hi-Hat Cymbals 2x



Crash/Ride Cymbal 1x



Drum Key 1x



Bass Drum Claws 16x



Drum Sticks 2x




Drum Pedal Padding 1x



Tom Drum rods 32x




Bass Drum Rods 16x



Floor Tom Legs 3x



Tom Drum Arms 2x




Bass Drum Legs 2x



Hi-Hat Stand 1x



Cymbal Stand 1x



Snare Stand 1x



Drum Seat 1x

### Assembling Snare Drum Stand

(Unpack the snare stand. It will be in 2 pieces with the snare drum already assembled)

1. Insert the top of the snare stand into the base & use the wing nut to lock it into place. Spread your snare drum arms.
2. Place your snare drum onto the stand & use the wing nut on the bottom of the arms to lock the snare drum.



### Assembling the Bass Drum (First unpack the bass drum, heads, hoops, & legs)

1. Place the logo drum head on the front, this is the side that the **bass drum legs** will be attached to. Place the drum head onto the bass drum followed by the bass drum hoops for the top and bottom.
2. Place your **bass drum rods** through the **bass drum claws**, & use them to attach the hoop and drum heads to the bass drum. Then grab the **drum key** to lock in & tighten the rods.
3. Insert **bass drum legs** through the holes under the drum head, and use the **drum key** to tighten and lock them in.
4. Assemble the **bass drum pedal and beater** together. Place the **drum pedal band** onto the drum hoop and attach the **bass drum pedal**.



### Assembling Floor Tom & Toms (Start w/ 16" floor tom, drum heads, hoops & legs)

1. Place the drum head onto the drum shell. The drum head w/ the Sawtooth logo will be your top (batter) head. Then collect 12 of the **small tom drum rods** & place the hoops on top & Bottom of the drum head.
2. When the hoops & **tom drum rods** are aligned, grab the **drum key** to lock in the rods & attach the drum head. Use this same process to assemble the other tom drums.
3. Place the **floor tom legs** through the holes around the rims and use the **drum key** to tighten and lock them in.



### Attaching the Toms to Bass Drum

(First unpack the tom arms)

1. Place the **tom arms** into the holes on top of the bass drum, lining up the collar to lock into place. They should be facing outwards.
2. Place the 12" tom on the **left tom arm** and the 13" tom on the **right tom arm**. Reverse if you play left handed.



(Note: Adjust tom locations to your preference. Use a **drum key** to lock and unlock the collars on the tom arms)

# Rise by SanTooth Student Drum Set (ST-RISE-DS)

## Assembly Instructions

(Continued)

### Assembling Hi-Hat Stand (When you unpack your hi-hat stand it will be in two pieces. Note: maintain 1/4" – 1/2" between the two cymbals.)


1. Start with the bottom half. Lay the hi-hat pedal flat & squeeze the two metal prongs on the bottom of the pedal. Insert these two prongs into the two holes found at the very bottom of the hi-hat stand.



2. Use the wing nut to loosen the legs of the stand, then spread them so the hi-hat pedal lays flat & the legs all touch the ground. The stand should not be able to pivot on the pedal.



3. Remove the rod from the top half of the hi-hat stand & thread it into the receiving end in the bottom half of the hi-hat stand.



4. Remove the hi-hat clutch from the rod using the wing nut to insert the top half of the hi-hat stand into the bottom half. Use the wing nut at the top of the base to lock it in place.



5. Place one 14" hi-hat onto the stand with the bell facing down.



6. Remove the plastic nut & one felt from the hi-hat clutch.



7. Place the clutch through your other 14" hi-hat with a felt on each side. The bell should be facing the wing nut on the hi-hat clutch.



8. Place assembled top hi-hat onto the hi-hat rod and use the wing nut to lock the clutch in your desired location. Should be approx. 1/2" apart



### Assembling Crash/Ride Cymbal (Unpack the cymbal stand.)

1. Spread the stand legs using the attached wing nut.



2. Extend the cymbal stand using wing nuts in the middle of the stand.



3. Remove wing nut, washer, & 1 cymbal felt. Place cymbal on the top, w/ the bell facing upwards & put it all back on in order removed.



4. Use tiltor just under the crash/ride cymbal to adjust the lean of the cymbal.



### Assembling Drum Seat

1. When you unpack the drum seat it'll have 3 separate pieces



2. Insert the ridged end of the rod under the seat cushion & tighten the wing nut on the cushion.



3. Insert the other end of the connecting rod into the tripod base of the drum seat & tighten the wing nut on the connecting rod around the base rod. To open the legs of the tripod, loosen the wing nut on the tripod base and slide the collar down. Re-tighten the wing nut to hold in place.

